





## Clean Your Own Grease Trap in 8 Easy Steps


1. Detach cover gently with pry bar.




2. Inspect grease trap parts once lid is removed.



4. Remove the solid waste from inside the trap using a small bucket or scoop.



3. Use a small bucket or scoop to remove all standing water from inside your trap.



5. Scrape down the sides and lid with a putty knife and remove material with a shop vac.



6. Clean the lids, sides and interior parts with soap and warm water.



8. Document service on FOG report for your records.



7. Re-install all parts by following your diagram.

